



Master Stop Tape Installation Instructions

- Testing of adhesive before installation is suggested.
- Surface temperature must be above 55°.
- Apply to smooth surface. Repair application area by filling in any cracks and pits. Seal porous surfaces. DO NOT apply over grout lines.
- Clean surface using industrial cleaner. Remove any oils, dirt, and flaking paint.
- Flush surface to remove any soap residue.
- Allow ample dry time.
- Cut to size. Rounding corners is suggested.
- Peel off paper backing. Keeping fingers off adhesive.
- Position and Press in to place, pushing from the center out to the edges to remove any air bubbles. For enhanced bond use a rubber hand roller.
- Ready for immediate use.
- Surface can be cleaned using mild floor cleaner as directed.